

## 126-6 PALM HAMMER

INDEX NO.	PART NO.	DESCRIPTION	NO. REQ'D
1	89801	Housing	1
2	89802	"O" Ring	1
3	89803T	Hammer Tip -15SS (Super Soft Plastic)	1
	89803T	Hammer Tip -15S (Soft Plastic)	1
	89803T	Hammer Tip -15M (Medium Plastic)	1
	89803T	Hammer Tip -15H (Hard Plastic)	1
	89803T	Hammer Tip -15AL (Aluminium)	1
	89803T	Hammer Tip -15ST (Steel)	1
4	89804	Stroke Control Spacer	1
5	89805	Sleeve	1
6	89806	"O" Ring	1
7	89807	Valve	1
8	89808	"O" Ring	1
9	89809	Bumper	1
10	89810	"O" Ring	2
11	89811	Stem	1
12	89812	Screw	1
13	89813	Plug	1
14	89814	Exhaust Seat	1
15	89815	"O" Ring	1
16	89816	Cap	1
17	89817	Screw	4

