


470 & 472 7" Angle Sander / Polisher



33a Haas Road, Toronto, On M9W 3A1
 Tel: 416-748-0707 1-888-748-0707
 Fax: 416-748-0706 E-mail: sales@justools.com

Index No.	Parts No.	Description	Index No.	Parts No.	Description
1	6N-666101	Motor Housing	24	6N-666124	Spindle
2	6N-666102	Valve Housing	25	STW15	Retaining Ring (STW-15)
3	6N-666103	Air Inlet	26	WW16	Spring Washer (WW-16)
4	5G-619704	Throttle Lever	27	6N-666127	Pinion Gear
5	6N-666105	Valve Pin	28	6N-666128	Bevel Gear
6	32-301210	Valve	29	6N-666111	Spacer
7	32-301207	Valve Seat	30	RTW40	Retaining Ring (RTW-40)
8	32-301206	Spring	31	61934	Key (3x13)
9	STW5	Retaining Ring (STW-5)	32	080227	Ball Bearing (6201z)
10	5G-619702	Spring	33	6N-666113	Spindle Cap
11	5G-619707	Safe Lever	34	61902	Spring Pin (4x28L)
12	6N-666137	Screw (8) (M5X22L)	35	06203Z	Ball Bearing (6203z)
13	40344	Washer (8) (M5)	36	6N-666132	Back Disc
14	5D-619014	End Plate	37	6N-666133	Disc Nut
15	6N-666115	Rotor	38	6N-666123	Exhaust Diffuser
16	61816	Rotor Blade(4)	39	6N-666152	Rubber Grip
17	5D-619024	Exhaust Deflector	40	6N-666129	Shaft
18	5D-619018	Cylinder	41	6N-666108	Spring
19	61819	Front End Plate	42	6N-666130	Press Button
20	6N-666117	Gasket	43	5G-619751	Handle
21	40317-14	Spring Pin (3x8L)	44	619554	Pin Wrench
22	40317-13	Spring Pin (3x12L)	45	6N-666138	Bushing
23	030120	Ball Bearing(3) (608zz)			