


6902K UTILITY IN-LINE DRIVER



33a Haas Road, Toronto, On M9W 3A1
Tel: 416-748-0707 Fax: 416-748-0706
1-888-748-0707 E-Mail: sales@justools.com

Index No.	Parts No.	Description	Index No.	Parts No.	Description
1	301101	Motor Housing	34	690134	Toothed Belt
2	30102	Spring Pin (3*24L)	36	040313	Ball Bearing (6001Z)
3	51203	Air Inlet	37	690121	Key(2) (3*10)
4	6K-301104	Throttle Lever	38	690111	Toothed Washer (BW-4.5)
5	6K-301105	Valve Stem	39	690110	Screw
6	51206	Exhaust Deflector	40	522239	Safety Bar
7	70107	O-Ring (4.8*1.9)	41	6K-301151-0002	Spring
8	51208	Spring	42	51542	Spring Pin (2*18L)
9	70123	O-Ring (11.8*2.4)	43	690137	Handle
10	51210	Throttle Valve Plug	44	690107	Plastic Housing(R)
11	40305	O-Ring (6.5*2)	45	690120	Belt Drive Shaft
12	690112	E-Ring (ETW-8)	46	0690108	Ball Bearing (LF-688ZZ)
13	052213	Ball Bearing (696ZZ)	47	690108	Plastic Housing(L)
14	301114	End Plate	48	690117	Set Srew(2) (M4)
15	95-301115	Rotor	49	690109	Toothed Pulley(2)
16	512216	Rotor Blades(4)	51	690113	Inner Bulkhead
17	30117	Spring Pin (1.5*6L)	52	690122	Bevel Gear
18	512218	Cylinder	53	206077	Hexagonal Hole Screw (M6*20L)
19	95-301119	Front End Plate	54	690136	Dust Cover
20	030120	Ball Bearing (2) (608ZZ)	56	690123	Spindle
21	51221	Air Regulator	57	051220	Ball Bearing (6000ZZ)
22	70922	Internal Gear	58	10018	Hex. Key Wrench (5mm)
23	690146	Planet Gear(2)	59	512252	Grip
25	746425	Pin(2) (4*14.8L)	60	30117-22	Spring Pin(2) (1.5*4)
26	690126	Planet Cage	61	690145	Bushing(2)
27	690127	Tapping Screw(4) (TS 2.9*20L)	62	95-301120	Decoration Ring
28	690128	Tapping Screw(8) (TS2.9*16L)	63	51250	Muffler
29	51229	Retaining Ring	64	0688ZZ	Ball Bearing (688ZZ)
30	690130	Bevel Gear	65	030113	Ball Bearing (626ZZ)
31	690131	Nut			
32	690132	Housing Cap			
33	690133	Toothed Washer			