




A39BPN 1/4" Adjustable Clutch Screwdriver



No.	Part No.	Part Name	Q.	No.	Part No.	Part Name	Q.	No.	Part No.	Part Name	Q.
1	5L2108	Pistol Housing	1	21	1S3044	10T Rotor [A45]	1	36	5A5352	Clutch Housing	1
2	7Q2008	O Ring	1	22	1S3045	Rotor [A39]	1	36-1	4W6023	Washer	1
3	2C2003	Blank Cap	1	23	1P3051	Blade	6	37	3S2028	Anvil	1
4	7Q2006	O Ring	1	24	1P3061	Front Plate	1	38	6N2081	C Ring	1
5	7Q6112	Valve O-Ring	1	24-1	6S2014	Pin	1	39	7S2112	Ball	3
6	6S2023	Valve Pin	1	25	7S2011	Ball Bearing	1	40	2S5233	Washer	1
7	6N2106	Cone Spring	1	26	6N2020	C Ring [A45]	1	41	6N3017	Torque Spring[A39]	1
8	6S2024	Valve Bushing	1	27	1S3050	Connect [A39]	1	41-1	6N3016	Torque Spring[A45]	1
8-1	7Q2009	O Ring	2	28	1P2270	18T Main Gear [A39]	1	42	3S3222	Regulation Washer	1
9	5L2701	Button	1	28-1	1S2063	Internal Gear [A45]	1	43	3A3033	Torque Ring	1
10	5L2116	Cap	2	29	1P2110	12T Plant Gear [A39]	4	44	6N3301	C Ring	1
11	2Q5001	O Ring	2	29-1	1P2101	15T Plant Gear [A45]	4	45	7S3107	Ball	1
12	2S2011	Screw Cap	2	30	1P2291	Third Gear Cage [A39]	1	46	6N2110	Spring	1
13	6N2108	Spring	1	30-1	1P3281	Fifth Gear Cage [A45]	1	47	5S2001	Bit Slide Sleeve	1
14	7Q2017	Valve O-Ring	1	31	1P5101	14T Main Gear [A39]	1	48	6N2001	C Ring	1
15	2P6005	Valve	1	31-1	1G6085	10T Main Gear [A45]	1	49	5L2202	Pistol Cover	1
16	7S2107	Set Screw And Washer	1	32	1P2131	14T Plant Gear [A39]	4	50	2Q5001	O Ring	1
17	2L3011	Switch	1	32-1	1P2101	15T Plant Gear [A45]	4	51	2S2005	Air Inlet Bushing [PT]	1
18	7S2001	Ball Bearing	1	33	1P2290	Fourth Gear Cage [A39]	1	51-1	2S2008	Air Inlet Bushing [PS]	1
19	1S3001-A	End Plate	1	33-1	1P3280	Fifth Gear Cage [A45]	1	51-2	2S2006	Air Inlet Bushing [NPT]	1
19-1	6S2013	Pin	1	34	1S3156	Internal Gear	1	52	2P3040	First Silencer	1
20	1P3005	Cylinder	1	35	7S2010	Ball Bearing	2	53	2P3024	Second Silencer	1

Just Tools Inc.

33A Haas Road, Toronto, On M9W 3A1

416-748-0707 Toll Free: 1-888-748-0707

Fax: 416-748-0706 E-mail: sales@justtools.com