


# AirPro A58BPN Air Screwdriver



No.	Part No.	Part Name	Q.	No.	Part No.	Part Name	Q.	No.	Part No.	Part Name	Q.
1	5L2027	Pistol Housing	1	21	1S6048	6T Rotor [A48]	1	36-1	2Q2003	O Ring	1
2	7Q2008	O Ring	1	22	1S6047	10T Rotor [A58]	1	37	3S5040	Anvil	1
3	2C2003	Blank Cap	1	23	1P6051	Blade	6	38	6N2081	C Ring	1
4	7Q2006	O Ring	1	24	1P6062	Front Plate	1	39	7S2105	Ball	3
5	7Q6112	Valve O-Ring	1	24-1	7S2102	Ball	36	40	2S5233	Washer	1
6	6S2023	Valve Pin	1	25	7S2011	Ball Bearing	1	41	5N5210	Torque Spring [A48]	1
7	6N2106	Cone Spring	1	26	6N2020	C Ring [A58]	1	41-1	6N5211	Torque Spring [A58]	1
8	6S2024	Valve Bushing	1	27	1S3050	Connect [A48]	1	42	3S3221	Regulation Washer	1
8-1	7Q2009	O Ring	2	28	1P2271	21T Main Gear [A48]	1	43	3A6301	Torque Ring	1
9	5L2701	Button	1	29	1P2102	10T Plant Gear [A48]	7	44	6N3301	C Ring	1
10	5L2116	Cap	2	29-1	1P2101	15T Plant Gear [A58]	4	45	7S3107	Ball	1
11	2Q5001	O Ring	2	30	1P6294	Third Gear Cage [A48]	1	46	6N2110	Spring	1
12	2S2011	Screw Cap	2	30-1	1P3280	Fifth Gear Cage [A58]	1	47	5S2001	Bit Slide Sleeve	1
13	6N5006	Spring	1	31	1G6271	21T Main Gear [A48]	1	48	6N2001	C Ring	1
14	7Q2011	Valve O-Ring	1	31-1	1G6090	14T Main Gear [A58]	1	49	5L2201	Pistol Cover	1
15	2P6003	Valve	1	32	1P6111	10T Plant Gear [A48]	7	50	2Q5001	O Ring	1
16	7S2107	Set Screw And Washer	1	32-1	1P6130	14T Plant Gear [A58]	4	51	2S2005	Air Inlet Bushing [PT]	1
17	2L6011	Switch	1	33	1P6295	Third Gear Cage [A48]	1	51-1	2S2008	Air Inlet Bushing [PS]	1
18	7S5001	Ball Bearing	1	33-1	1P6288-1	Fourth Gear Cage [A58]	1	51-2	2S2006	Air Inlet Bushing [NPT]	1
19	1S6001-A	End Plate	1	34	1S3157	Internal Gear	1	52	2P3025	First Silencer	1
20	1P6005	Cylinder	1	35	7S2010	Ball Bearing	2	53	2P3041	Second Silencer	1
20-1	2S2023	Key	1	36	5A5354	Clutch Housing	1				