





# S-319K Reciprocating Saw Kit

Just Tools Inc.

33 Haas Road, Toronto, On M9W 3A1 Tel: 416-748-0707 Fax: 416-748-0706

1-888-748-0707 E-mail: sales@justtools.com



## PARTS LIST

Index	Part #	Description	Index	Part#	Description	Index	Part#	Description
1.	314403	Cylinder Head Ass'y	17.	EC1317	Retaining Ring	33.	319703R	Right Outer Housing
2.	OR0812	O-Ring (4)	18.	<b>315409</b>	<b>Main Liner</b>	34.	<b>319703L</b>	<b>Left Outer Housing</b>
3.	RP2006	Front Dowel Pin (2)	19.	318607	Shock Absorbent Spring	35.	315601	Safety Lever Ass'y
4.	314408	Bumper	20.	316407M	Blade Holder Ass'y	36.	RP3022	Rear Dowel Pin
5.	315402	Piston Ass'y	21.	318102	Sliding Liner	37.	318705	Lock Nut-Front
6.	314405	Gasket	22.	319202	Connecting Hose	38.	318707	Lock Nut-Rear
7.	314401	Cylinder	23.	319608	Spring	39.	318706	Saw Blade Guide
8.	RP2020	Rear Dowel Pin (2)	24.	319203	Lid-Valve	40.	NN0407	Nut (4)
9.	314302	Automatic Valve	25.	319204	Valve Case	41.	040705	Screw (2)
10.	314311	Valve Chest	26.	040712	Screw (6)	42.	061008	Set Screw
11.	314303	Valve Seat	27.	OR0507	O-Ring	43.	314918Z	18T Saw Blade
12.	315304	Valve Cap	28.	314602	Valve Stem		314924Z	24T Saw Blade
13.	318203	Rubber Washer	29.	OR0307	O-Ring		314932Z	32T Saw Blade
14.	318704	Muffler Cap	30.	318603	Spring	44.	314933	3mm Hex Wrench
15.	301709	Muffler	31.	182808	Plug Screw	45.	922A18	1/4"NPT Universal Swivel Air Inlet Joint (opt.)
16.	318211	Adaptor	32.	319702	Air Inlet			