



MODEL NO :
 SKD - 5200PB (UL)
 SKD - 5300PB (UL)

NO	PARTS NO	PARTS NAME-E	Q'ty	NO	PARTS NO	PARTS NAME-E	Q'ty
1	AA50001	CORD ASSEMBLY	1	33	GO33315	INNER SPRING	1
2	CA33402-4	HOUSING-UPSIDE	1	34	GP21291B	BIT PILOT FOR 6.35mm TYPE	2
3	CB33401-4	HOUSING-UNDERSIDE	1	35	GP30351	STEEL BALLS	2
4	CD20111	COUPLER	1	36	GP30371	STEEL BALLS	2
5	CE90101	SWITCH BASE	1	37	GQ21361	"C" RING FOR GJ3046B	1
6	CH20102	SCREW	3	38	GS30501	"C" RING FOR GM30491	1
7	CH90121	SCREW	1	39	GU30361	STOP PILOT	1
8	CH90131	SCREW	1	40	GV33316	INNER SPRING CAP	1
9	CH90151	SCREW	2	41	GX33318	SHAFT GUIDE FOR 5300P	1
10	CI33211-2	CHANGEOVER COVER FOR 5200P	1	42	GX33318-1	SHAFT GUIDE FOR 5200P	1
11	CI33211-3	CHANGEOVER COVER FOR 5300P	1	43	GY33313	WRING SPRING BASE	1
12	CJ20011	SUSPENSION RING	1	44	GZ33371-3B	CLUTCH ASSEMBLY FOR 5300PB	1
13	EE30521-1	COIL	1	45	GZ50072PB	CLUTCH ASSEMBLY FOR 5200PB	1
14	EF51431-1	CAPACITOR	1	46	HA28071-1	CHANGEOVER SWITCH ASSEMBLY	1
15	GA30311-3	GEAR CASE	1	47	HB50061	STOP SWITCH	2
16	GB20381-9	CLUTCH CASE	1	48	MA20211	ASSEMBLING SPRING	2
17	GD33319B	SHAFT FOR HEX6.35mm	1	49	MB20221	MOTOR END COVER	1
18	GE30411-6	WARNING SPRING FOR 5300P	1	50	MC71411	CARBON BRUSH	2
19	GE30411-8	WARNING SPRING FOR 5200P	1	51	MD20151	BRUSH CAP	2
20	GF33317	WARNING PLATE	1	52	ME20181	ARMATURE BEARING	2
21	GG20261	GEAR SEAT	1	53	MG30081	PILOT ROD	1
22	GG20271	GEAR SEAT	1	54	MH50601	ARMATURE FOR 5200P	1
23	GH20241	IDLE GEAR	8	55	MH50601-1	ARMATURE FOR 5300P	1
24	GI20251	IRON WASHER	1	56	MI33241	PILOT ROD	1
25	GJ3046B	BIT SLEEVE	1	57	MI33511-1	PILOT ROD	1
26	GK20231-1	"C" RING FOR GH20241	1	58	MJ30631	MOTOR YOKE ASSEMBLY FOR 5300P	1
27	GL30481	TORQUE ADJUSTING PINS	4	59	MJ50631	MOTOR YOKE ASSEMBLY FOR 5200P	1
28	GM30491	TORQUE ADJUSTING RING	1	60	MK20131	FAN	1
29	GN30321	MAIN BEARING	2	61	ML50571-1	MOTOR TOP COVER	1
30	GO20391B	BIT SPRING	1	62	MO50111-4	MOTOR ASSEMBLY FOR 5200P	1
31	GO30531-1	SPRING CAP FOR 5200P	1	63	MO50111-5	MOTOR ASSEMBLY FOR 5300P	1
32	GO30541	SPRING FOR 5200P	1	64	PZ50160	PLACTIC PLUG (MALE)	1