




T-6 Air Tamper Parts List



MODEL CODE : 51-06-01

Symbol No.	Parts No.	Description	Q'ty Req.
001	41-06-01-45A	HANDLE	1
002	13-08-01-078	THROTTLE VALVE SPRING	1
003	13-11-08-008	O RING P-10	1
004	13-08-01-079	THROTTLE LEVER RING	1
005	41-06-01-110	THROTTLE LEVER	1
007	41-06-01-080	THROTTLE VALVE	1
008	13-06-06-022	SPRING PIN 6X22	1
009	13-11-01-020	O RING P-22	1
010	13-49-05-020	THROTTLE VALVE CAP	1
011	41-06-01-541	CONNECTING PIPE	1
013	41-06-01-550	CONNECTING PIPE LOCK NUT	1
014	41-06-01-031	CYLINDER CAP	1
015	13-49-03-002	OIL PLUG 1/4	1
016	41-06-01-040	CYLINDER CAP BUSHING	1
017	41-06-01-590	OIL FEEDER	1
018	41-06-01-260	UPPER VALVE PLATE	1
019	41-06-01-280	CENTER VALVE PLATE	1
020	41-06-01-150	VALVE	1
021	13-04-01-092	VALVE KNOCKING PIN	2
022	41-06-01-270	LOWER VALVE BLOCK	1
023	13-11-01-033	O RING P-32	1
024	41-06-01-010	CYLINDER	1

Symbol No.	Parts No.	Description	Q'ty Req.
025	41-06-01-601	EXHAUST DEFLECTOR	1
026	41-06-01-610	PACKING NUT	1
027	41-06-01-620	LOCK RETAINER	1
028	41-06-01-320	INNER BUSHING	1
029	13-11-01-035	O RING P-35	2
030	13-61-01-034	UPPER PACKING	1
031	13-61-01-035	CENTER PACKING	1
032	13-61-01-036	LOWER PACKING	1
033	41-06-01-330	OUTER BUSHING	1
034	41-06-01-290	PISTON	1
035	41-06-01-650	BUTT SCREW	1
036	41-06-01-630	CLAMP SCREW	1